

Spreader Settings

Use the 'overlap' or 'double pass' method where indicated. This means applying the required amount in two half doses rather than all in one go. This gives a more even coverage and is more forgiving of missed or uneven spreading. The setting numbers below are for the indicated double or single pass spreading and do not need halving or doubling.

The following are settings to apply the quantity stated with a moderate walking speed of about 2.5 to 3mph. They are a guide only and **will need adjustment** as your walking speed, spread width and spreader condition will vary from those used. Therefore, **we suggest using the lowest setting indicated** when using your spreader for the first time with Lawnsmith Fertiliser. Adjust settings the next time you fertilise.

For spreading procedure watch the videos and animation in the video section at www.lawnsmith.co.uk. If you have a spreader other than that listed watch the spreader calibration video.

For Rotary or Broadcast Spreaders:

If your spread width is wider by more than 0.5m than that stated, slow down just a bit.

If your spread width is narrower by more than 0.5m than that stated, speed up just a bit.

Scotts EasyGreen Rotary Spreader

Warning

The screw connector that connects the cable from the handle to the base can come loose. Ensure this is tight before proceeding.

Always shut off the hopper BEFORE stopping the spreader.

We were not able to find low enough numbers on the dial for some products so you will have to test lower settings yourself.

Scotts EvenGreen & EverGreen Drop Spreaders

Warning

Due to the thin fairly smooth wheels this spreader can lose traction with a light load of granular product. You may need to apply some downward pressure on the handle to keep the drive wheel turning.

These spreaders, as with many budget drop spreaders, do not have the refined calibration to enable OVERLAP spreading with our professional turf fertilisers. In addition, we were not able to find low enough numbers on the dial for some products so you will have to test lower settings yourself.

On the EvenGreen: the screw connector that connects the cable from the handle to the base can come loose. Ensure this is tight before proceeding.

Earthway 2750 Shoulder Spreader example setting:

Setting 4 Open position. Hopper lever pulled backwards and held behind the setting bar so that the hopper is now open in the spreading position.



Cresco 5 Shoulder Spreader example setting:

Setting 4 Open position. Hopper lever pulled upwards and held on top of the setting bar so that the hopper is now open in the spreading position.



SPREADER SETTINGS

Set your spreader to the red number based on the grams, product and setting letter (A-J) found in the bottom right-hand corner of your fertiliser label.

The setting numbers are for the indicated double or single pass spreading and **do not need halving or doubling**.

	Cresco CR5 Shoulder Spreader						SETTING IS FOR	
	Grams per Square Metre						Single Pass	Spread
	20	25	30	35	40	45	Double Pass	Width
SPRING & SUMMER Clay or Sand (A)	4.75	5	5.25	5.5			Double	4.5m
SPRING & SUMMER Natur (G)	4.25	4.5	4.75	5			Double	4.3m
Extra-LONG (B)	4.75	5	5.25	5.5	6	Fully Open	Double	5m
AUTUMN (E)	4.5	4.75	5	5.25			Double	4.4m
WINTER GREEN (D)	4	4.25	4.5	4.75	5		Double	4.4m
STARTER (J)	4.75	5	5.25	5.5			Double	5.3m

	Cresco 20 and 30 Rotary Spreader						SETTING IS FOR	
	Grams per Square Metre						Single Pass	Spread
	20	25	30	35	40	45	Double Pass	Width
SPRING & SUMMER Clay or Sand (A)	9	9.5	10.5	11			Double	3.2m
SPRING & SUMMER Natur (G)	6.5	7.5	8.5	9			Double	3.3m
Extra-LONG (B)	9	10	11	12	13	13.5	Double	4.6m
AUTUMN (E)	9	9.5	10	10.5			Double	3.8m
WINTER GREEN (D)	6	6.5	7	7.5	8.5		Double	3.3m
STARTER (J)	7	7.5	8.5	9			Double	4m

Setting (Letter) found bottom right of product label	Scotts Easygreen Rotary Spreader						SETTING IS FOR	
	Grams per Square Metre						Single Pass	Spread
	20	25	30	35	40	45	Double Pass	Width
SPRING & SUMMER Clay or Sand (A)	23	24	25	26			Double	3 metres
SPRING & SUMMER Clay or Sand (C)	22	23	24	25			Double	3 metres
SPRING & SUMMER Natur (G)	trial & error	22	23	24			Double	2.5 metres
Extra-LONG (B)	22	23	24	25	26	27	Double	3 metres
AUTUMN (D)	trial & error	trial & error	22	23			Double	2.5 metres
AUTUMN (E)	22	23	24	25			Double	3 metres
WINTER GREEN (D)	trial & error	trial & error	22	23			Double	2.5 metres
STARTER (F)	23	24	25	26			Double	3 metres
STARTER (J)	22	23	24	25			Double	3 metres

Set your spreader to the red number based on the grams, product and setting letter (A-J) found in the bottom right-hand corner of your fertiliser label.

The setting numbers are for the indicated double or single pass spreading and **do not need halving or doubling.**

		Scotts Evergreen Drop Spreader						SETTING IS FOR	
Setting (Letter) found bottom right of product label	Grams per Square Metre						Single Pass	Double Pass	
	20	25	30	35	40	45			
SPRING & SUMMER Clay or Sand (A)	4	5	6	6.5				Single	
SPRING & SUMMER Natur (G)	3	3.75	4.5	5				Single	
Extra-LONG (B)	3.25	4	4.75	5.5	6	6.5		Single	
AUTUMN (E)	3.25	4	4.75	5.5				Single	
WINTER GREEN (D)	2.5	2.75	3	3.5				Single	
STARTER (J)	3.25	4	4.75	5.5				Single	

		Scotts Evergreen Drop Spreader						SETTING IS FOR	
Setting (Letter) found bottom right of product label	Grams per Square Metre						Single Pass	Double Pass	
	20	25	30	35	40	45			
SPRING & SUMMER Clay or Sand (A)	5	5.25	5.5	5.75				Single	
SPRING & SUMMER Natur (G)	4.25	4.5	4.75	5				Single	
Extra-LONG (B)	4.75	5	5.25	5.5	5.75	6		Single	
AUTUMN (E)	4.75	5	5.25	5.5				Single	
WINTER GREEN (D)	4	4.25	4.5	4.75				Single	
STARTER (J)	4.75	5	5.25	5.5				Single	

		Earthway 2750 Shoulder Spreader						SETTING IS FOR	
Setting (Letter) found bottom right of product label	Grams per Square Metre						Single Pass	Spread Width	
	20	25	30	35	40	45	Double Pass		
SPRING & SUMMER Clay or Sand (A)	4.5	5	5.25	5.5			Double	4 metres	
SPRING & SUMMER Clay or Sand (C)	4.2	4.5	4.7	5			Double	4 metres	
SPRING & SUMMER Natur (G)	3.7	4	4.2	4.4			Double	3.5 metres	
Extra-LONG (B)	4.2	4.5	4.7	5	5.3	5.5	Double	4 metres	
AUTUMN (D)	3.4	3.7	4	4.2			Double	3.5 metres	
AUTUMN (E)	4.2	4.5	4.7	5			Double	4 metres	
WINTER GREEN (D)	3.4	3.7	4	4.2			Double	3.5 metres	
STARTER (F)	4.5	5	5.25	5.5			Double	4 metres	
STARTER (J)	4.2	4.5	4.7	5			Double	4 metres	

Set your spreader to the red number based on the grams, product and setting letter (A-J)
 The setting numbers are for the indicated double or single pass spreading and **do not need halving or doubling.**

Setting (Letter) found bottom right of product label	Earthway 2600A+ Rotary Spreader						SETTING IS FOR	
	Grams per Square Metre						Single Pass	Spread
	20	25	30	35	40	45	Double Pass	Width
SPRING & SUMMER Clay or Sand (A)	13	14	15	16			Double	2.5 metres
SPRING & SUMMER Clay or Sand (C)	12	13	14	15			Double	2.5 metres
SPRING & SUMMER Natur (G)	11	12	13	14			Double	2 metres
Extra-LONG (B)	12	13	14	15	16	17	Double	2.5 metres
AUTUMN (D)	10	11	12	13			Double	2 metres
AUTUMN (E)	12	13	14	15			Double	2.5 metres
WINTER GREEN (D)	10	11	12	13			Double	2 metres
STARTER (F)	13	14	15	16			Double	2.5 metres
STARTER (J)	12	13	14	15			Double	2.5 metres

Setting (Letter) found bottom right of product label	Earthway 7300/7312 Drop Spreader						SETTING IS FOR	
	Grams per Square Metre						Single Pass	
	20	25	30	35	40	45	Double Pass	
SPRING & SUMMER Clay or Sand (A)	21	22	23	24			Single	
SPRING & SUMMER Clay or Sand (C)	20	21	22	23			Single	
SPRING & SUMMER Natur (G)	18	19	20	21			Single	
Extra-LONG (B)	20	21	22	23	24	25	Single	
AUTUMN (D)	16	17	18	19			Single	
AUTUMN (E)	20	21	22	23			Single	
WINTER GREEN (D)	16	17	18	19			Single	
STARTER (F)	21	22	23	24			Single	
STARTER (J)	20	21	22	23			Single	